

Construction site preparation

The following conditions must be met in the building before pur natur planks can be installed. Please also note the recommendations in our installation instructions for pur natur planks.

In Summer: The floorboards must be laid immediately after delivery.

In Winter: The floorboards must acclimatise in the installation room under correct climatic conditions for at least 5-7 days. The air humidity must not exceed 50%.

Advice for builders

You must ensure that the following conditions are met before instructing craftsmen to install the product. If you do not follow these instructions, you will not be able to make any legal claims in the event of defects. Craftsmen are entitled to suspend their work in the absence of essential preconditions, with the right to claim downtime and travel time.

Advice for craftsmen

Please note that the necessary preconditions and room climatic conditions must be observed. Failure to do so may result in consequential damage to the floor, among other elements.

Have the builder confirm the required conditions on the construction site before starting the work. If you do not find the necessary conditions, establish them first before you start laying.

It is imperative that you check the general building moisture, temperature, humidity and moisture in the substrate or substructure according to our specifications.

Necessary preconditions

- > The building is closed, dry and moisture-relevant trades have been carried out. The air humidity is 40-60% (in winter max. 50%), temperature at least 18 °C.
- > A heating protocol has been carried out and rooms have been heated continuously for at least three weeks prior to installation with humidity not exceeding 60%.
- > The construction moisture for screed with underfloor heating is $\leq 1.8\%$ CM, for a substructure made of wood the wood moisture is max. 10-12%.
- > Measurement protocols for subsoil moisture are sufficiently documented.
- > Subsoil flatness according to DIN has been tested and is not greater than 2mm on a 2m standard lath.

Confirmation for executing craftsmen:

I have read the above instructions. All necessary preconditions for the installation of pur natur floorboards have been checked and complied with. The installation of the planks can be started.

Place, date, building supervision/building owner